

Tack Mount Graphic films

Application instructions



window films

Mounting \

1. The surface must be clean and smooth.
2. Spray water on the glass, varnished wood, metal, etc. before applying the film to the surface.
3. Peel off approximately 20 cm of the liner on the top side of the film.
4. Position the graphic so that it is exactly aligned on all sides and press the corners lightly in place.
5. Working from top to bottom, apply the graphic while peeling away the liner until it is completely removed.
6. Use a damp cloth to remove air bubbles.
7. To remove or re-position the graphic slowly pull it off.

Notes \

1. Spraying water on the surface before application makes it easier to remove air bubbles.
2. Do not use sharp objects to remove the air bubbles, this may damage the graphic.
3. It is possible to re-use the graphic, the micro-suction layer can be washed off with water (do not use soap).
4. Small pieces of dirt can be removed with adhesive tape.

Print recommendations \

1. Some printers do not detect Tack Mount Transparent or Tack Mount Ultra Clear. A piece of masking tape under/over the detector may solve this problem.

Do not leave the printer operating unattended in this situation, since the printer will not detect the end of the media and will continue printing.



www.tackmount.com

Important:

Before using the media the user must examine the suitability of the media for each application. We shall not assume liability for non-performance of the media. Specifications are subject to change without notice.